

FOOTWELL MOUNTED AIR CONDITIONING KIT **INSTALLATION GUIDE**

JAGUAR E TYPE V12

DOCUMENT PART NUMBER: PDS2802 KIT: JAG/AC1024 AND? KIT: JAG/AC1008





Thank you for buying this Footwell Mounted Air Conditioning kit for V12 E-Types. This kit enables the evaporator and pipework to be mounted to the vehicle and completes the air conditioning installation

All of our kits have been custom designed in our workshops and rigorously developed and tested around the world. We're proud to set the standard for cooling performance.

We've designed this guide to make the install process as straightforward as possible, but if you need any help, have any questions, or can suggest any ways in which we can improve these guides, please do get in touch with our team via the details below.

Before you start, please make note of the following useful information:

- The mounting kit supplied has been designed to fit in a non modified Series 1 E Type. Non-standard auxiliary components, such as power steering pumps, external oil coolers etc, may prevent the air conditioning mounting brackets and components from fitting to the vehicle as designed. If any relevant parts of your vehicle have been modified, please contact us prior to starting your installation to discuss your options.
- The system is designed to use R134a refrigerant, to a weight of 600 grams +/- 50grams. You will need to add 60g of PAG-46 oil.





Contents

Parts Check List	Page 4
Installation Overview	Page 5
Step 1: Fitting the Evaporator Box	Page 6-12
Step 2: Pipework Assembly	Page 13-16
Step 3: Pipework & Fittings	Page 17-21
Step 4: Wiring Diagram	Page 22
Step 5: System Maintenance	Page 23

- 3 -

(in) (in)

f